



WATERPROOFING

SOPRASEAL[®] STICK 1100 T WALLS



SELF-ADHESIVE AIR/VAPOUR BARRIER MEMBRANE



SOPRASEAL STICK 1100 T is a self-adhesive air/vapour barrier membrane for walls composed of SBS modified bitumen and a tri-laminate woven polyethylene facer. It is also used as masonry and through-wall flashing membrane as well as waterproofing membrane at openings and transitions.

- Excellent adhesion to various substrates
- Ideal for sprayed polyurethane foam insulation
- Easy, fast and economical to install
- Self-sealing membrane ensuring continuous waterproofing

SURFACE PREPARATION

Substrates must be clean and dry, primed with Equus Peel & Stick Primer to ensure better adhesion.

COMPLEMENTARY PRODUCTS

EQUUS PEEL & STICK PRIMER

Used to prepare surfaces before the installation of self-adhesive membranes.

NEOPRENE ROLLER

Maximises SOPRASEAL STICK 1100 T adhesion.

SOPRASEAL SEALANT

SOPRASEAL STICK 1100 T

THICKNESS	1.0 mm
DIMENSIONS	0.91 x 22.9 m
SURFACE	Tri-laminate woven polyethylene
UNDERFACE	Silicone release paper



www.equus.nz

info@equus.nz

INSTALLATION INSTRUCTIONS

1



Prime the substrate with Equus Peel & Stick.

2



Peel off the top portion of the silicone release paper and adhere the membrane to the substrate, making sure the membrane is well aligned.

3



Gradually peel off the remaining silicone release paper, making sure the membrane adheres completely to avoid air pockets and wrinkles.

4



Use a roller to apply pressure over the entire surface of the membrane to ensure uniform adhesion to substrate.

5



Use SOPRASEAL SEALANT to seal around details, reverse laps and critical areas. For window openings, use a compatible sealant.

If you have any questions about this product or its installation, please contact Equus, your SOPREMA Authorised Distributor.