

Repairs Methodology – Chevaline Coverall/Colourglaze System

E-1 SPECIFICATION EXTERIOR WALL AREAS - Acrylic

July 2019

1.0 PREAMBLE

This specification is for the application of a touch up coating of the **Chevaline Coverall / Colourglaze System** as a long-life easy-maintenance waterproof coating system on damaged concrete panel surfaces

2.0 EQUUS COATING INSTALLATION PROCEDURES for exterior concrete panel surfaces

- Waterblast all concrete panels clean.
- Confirm that all panels are clean and dry. Sand any mechanically damaged coatings.
- Plaster concrete defects and chipped concrete with **Equus Admix Plaster**. Use **Chevaline Filprime** for minor defects. Consult Equus for accurate detailing procedures.
- Ensure any repaired sealants have had a 5-day cure period before over coating.
- Apply a **Chevaline Coverall Primer 50/50** spot coat to the repaired defects on the concrete panels.
- Apply the second spot coat of **Chevaline Coverall** at 4 m² per litre to the repaired areas.
- Apply the third coat of **Chevaline Colourglaze Topcoat** at 8 m² per litre to the complete panel.