



WATERPROOFING

SOPRASEAL® STICK 1100 T WALLS



SELF-ADHESIVE AIR/VAPOUR BARRIER MEMBRANE



SOPRASEAL STICK 1100 T is a self-adhesive air/vapour barrier membrane for walls composed of SBS modified bitumen and a tri-laminate woven polyethylene facer. It is also used as masonry and through-wall flashing membrane as well as waterproofing membrane at openings and transitions.

- Excellent adhesion to various substrates
- Ideal for sprayed polyurethane foam insulation
- Easy, fast and economical to install
- Self-sealing membrane ensuring continuous waterproofing

SURFACE PREPARATION

Substrates must be clean and dry, primed with Elastocol Stick to ensure better adhesion.

COMPLEMENTARY PRODUCTS

ELASTOCOL STICK Used to prepare surfaces before the installation of self-adhesive membranes.

NEOPRENE ROLLER Maximises SOPRASEAL STICK 1100 T adhesion.

SOPRASEAL SEALANT

SOPRASEAL STICK 1100 T	
THICKNESS	1.0 mm
DIMENSIONS	0.91 x 22.9 m
SURFACE	Tri-laminate woven polyethylene
UNDERFACE	Silicone release paper



www.equus.nz

info@equus.nz

INSTALLATION INSTRUCTIONS

1



Prime the substrate with Elastocol Stick.

2



Peel off the top portion of the silicone release paper and adhere the membrane to the substrate, making sure the membrane is well aligned.

3



Gradually peel off the remaining silicone release paper, making sure the membrane adheres completely to avoid air pockets and wrinkles.

4



Use a roller to apply pressure over the entire surface of the membrane to ensure uniform adhesion to substrate.

5



Use SOPRASEAL SEALANT to seal around details, reverse laps and critical areas. For window openings, use a compatible sealant.

If you have any questions about this product or its installation, please contact Equus, your SOPREMA Authorised Distributor.