



Chevaline Coverflexx/Colourglaze System

Membrane finish to smooth cementitious surfaces

Specification No: E-2 Exterior Wall Areas - Acrylic

Date Prepared: July 2019

Project & Address:

Certified Applicator:

Building Owner:

Project Manager:

1. Statement of Intent

- (a) This checklist is to be completed by both the Equus Applicator and the Building Contractor, as a step by step record of compliance with both the Equus Specification provided for the contract, and the requirements of the Manufacturer for warranty.
- (b) A copy of this checklist must be forwarded to the nearest Regional Office of Equus Industries Ltd a Warranty and/or Manufacturers Producer Statement. A Warranty will not be issued by Equus Industries Ltd. without a copy of this Checklist being filed.
- (c) A copy of this checklist should form part of the Contract Documentation filed with the Project Manager on job completion, for issuance of Compliance.

2. Areas Treated

The areas to which coating is applied are detailed below, with reference to plans (where appropriate).

3. Sign Off

We confirm that all applicable processes listed in Section 4 have been correctly completed and that sign-off on each stage has been made by a person with the authority to do so.

For: _____ (Signature)
(Building Contractor)

Date: ____ / ____ / ____ _____ (Name)

For: _____ (Signature)
(Equus Applicator)

Date: ____ / ____ / ____ _____ (Name)

For: **Equus Industries Ltd** _____ (Signature)
(Equus Representative)

Date: ____ / ____ / ____ _____ (Name)



4. Checklist And Method Statement

No.	Process	Min. WFT	Completed On	Certified Applicator	Equus Representative
1.	Waterblast all surfaces at 3000 PSI.				
2.	Confirm all release agents are removed. Scrub any residues with sugar soap and rinse clean. Allow to dry.				
3.	Plaster defects can be patched with Thermexx leveling plaster - consult Equus for procedures.				
4.	Install Tremco Dymonic FC polyurethane sealants. Allow these to cure 5 days.				
5.	Apply a coat of Chevaline Coverall 50/50 Primer at 8m ² per litre.	N/A			
6.	Apply a strip coat of Chevaline Coverflexx bodycoat at 3 m ² per litre over all cracks in the concrete.	250			
7.	Apply a Chevaline Coverflexx bodycoat at 3 m ² per litre. Dry overnight.	250			
8.	Apply a Chevaline Colourglaze bodycoat at 8 m ² per litre.	120			
9.	Darker colours will require a second coat of Chevaline Colourglaze .	120			