

Standard Specification for the installation of the EQUUS SOPREMA DUOTHERM Warm Roof System to metal tray surfaces

Project:
Prepared for:
Specification:
Date: November 2023
Page 1 of 6

1.0 PREAMBLE:

This specification is for the installation of the **EQUUS SOPREMA DUOTHERM** warm roof system over a new metal tray substrate. The system provides a durable, fully insulated and waterproof roof. As the insulation is continuous over the entire roof structure, thermal bridging is largely eliminated. The energy efficiency of the building is improved as a result thereby reducing heating and ventilation costs for the building owner.

The **EQUUS SOPREMA DUOTHERM** warm roof system consists of a torch applied or self-adhesive vapour barrier, PIR or mineral wool insulation (adhered or mechanically fixed) to the vapour barrier with a two-layer bitumen membrane system installed over the insulation to provide a fully waterproof and fire retardant covering for the roofing system.

The **EQUUS SOPREMA DUOTHERM** warm roof system has been assessed for use on roofs, decks and gutters installed on metal deck or panel, treated plywood and concrete substrates on buildings within the following scope:

- Buildings where the supporting structure and associated elements are designed and constructed within the scope of New Zealand Building Code E2/AS1 clause 1.1.
- Specifically designed buildings constructed to comply with the New Zealand Building Code.

2.0 SURFACE PREPARATION:

2.1 General - Responsibility:

Unless expressly agreed otherwise at time of contract pricing, all work in this section shall be the responsibility of the main contractor, whether carried out by their own staff, other sub-trades or the roofing membrane sub-contractor.

2.2 Metal tray substrate

Confirm metal tray substrate is minimum 0.7mm gauge reverse profile run metal roofing to AS 1562.1-1992 and HB 39-1997. Roof deck falls, gutter falls and outlets to NZBC E2/AS1.

2.3 Minimum Falls:

Ensure minimum falls for **EQUUS SOPREMA DUOTHERM** warm roof membrane systems are:

- The minimum fall for a roof and deck is not less than 1:80 (0.7°), to CodeMark CMNZ70151
- The minimum fall for a gutter is not less 1:100 (0.57°), to CodeMark CMNZ70151

2.4 Metal deck (existing roof):

Where existing metal roofing drops into the gutter, the iron overlap is to be cut back to allow a plywood upstand to be installed to the height of the insulation which will allow for the

membrane to continue into the gutter.

INSTALLATION:

Note: A prestart meeting should be held onsite with the Main Contractor and the Equus Certified Applicator prior to commencement of warm roof installation.

3.0 VAPOUR BARRIER:

3.1 Primer: (For details and upstands only)

To the dried and prepared surface apply one (1) full coat of **EQUUS PEEL AND STICK** primer at a spreading rate of 6 to 8 m²/L depending on the porosity of the substrate. Allow to dry for minimum one (1) hour depending upon prevailing weather conditions.

3.2 SOPRASTICK (previously known as DEBOTACK 2.5 T/F C175): (Self- adhesive)

Self-adhesive membrane for use as a vapour barrier when the PIR insulation is to be fully adhered by PU Foam.

Decide the most suitable direction to follow. Unroll and discard packaging. Align the first roll and cut to length as required. Remove the siliconized film and press the membrane into place on the surface. The self-adhesive properties are automatically activated during installation. Light heating is recommended at the edges to ensure all laps are fully closed. Repeat in sequence with all rolls, maintaining minimum laps of 100mm. Offset end laps in adjacent runs. Over upstands, the vapour barrier shall be taken up 50mm past the top of the insulation board. This ensures a suitable connection to create a complete waterproof envelope of the insulation.

3.3 COLPHENE 3000: (Self- adhesive)

Self-adhesive membrane for use as a vapour barrier when the insulation is to be mechanically fastened.

Decide the most suitable direction to follow. Unroll and discard packaging. Align the first roll and cut to length as required. Remove the siliconized film and press the membrane into place on the surface. The self-adhesive properties are automatically activated during installation. Repeat in sequence with all rolls, maintaining minimum laps of 100mm. Offset end laps in adjacent runs. Over upstands, the vapour barrier shall be taken up 50mm past the top of the insulation board. This ensures a suitable connection to create a complete waterproof envelope of the insulation.

4.0 INSULATION:

4.1 General:

On site cutting of boards is permitted and should be done using a fine-toothed saw or by scoring with a knife and snapping the board over a straight edge. Ensure accurate trimming to achieve a close tight butt finish. Any gaps between boards can be filled with Equus PU Foam.

Refer to Equus project specific data for fixing patterns and full installation instructions.

4.2 Mechanically fastened:

Where the base sheet is also mechanically fastened.

Install Equus PIR or mineral wool insulation in a brick bond pattern using full boards where possible. Use one fastener per board to tack in place before loose laying the base sheet also in place. Insulation is fully fastened with the base sheet installation as per section 6.1.

4.3 Mechanically fastened:

Where the base sheet is self-adhered.

Install the specified **EQUUS SOPREMA** fixings through the PIR or mineral wool insulation boards into the metal tray substrate following the project specific **SOPREMA** wind uplift report fixing layout plan. Ensure the fixings are securely fastened but not overly tightened to crush the insulation boards. Add pre-formed angle fillets in internal corners.

Note: In areas where mineral wool insulation is used, roofboard must also be installed.

4.4 Fully adhered:

Install Equus PIR insulation in a brick pattern using full boards where possible. Boards shall be fixed in place using **EASYFOAM** or **COLTACK EVOLUTION 750** adhesive applied in accordance with the fixing pattern in the project specific **SOPREMA** wind uplift report fixing layout plan. Multiple layers of board shall be glued with adhesive between each board.

5.0 ROOFBOARD: (where required)

5.1 Install **PERMABASE DEK** roofboard in a brick bond pattern over insulation, using full boards where possible. Boards shall be fixed in place using **EQUUS SOPREMA** fixings installed in accordance with the fixing pattern in the project specific Soprema wind uplift report.

5.2 Primer: (For fully torched base sheet)

The **PERMABASE DEK** roofboard shall be primed with **SOPRADERE QUICK** mixed and diluted 50/50 with white spirit. Apply one (1) coat of mixed material at a spreading rate of 6 to 8 m²/L by brush and/or roller. Allow to dry thoroughly before the selected base sheet is applied to the roofboard.

5.3 Primer: (For self-adhered base sheet)

The **PERMABASE DEK** roofboard shall be primed with one (1) full coat of **EQUUS PEEL AND STICK** primer at a spreading rate of 6 to 8 m²/L depending on the porosity of the substrate. Allow to dry for minimum one (1) hour depending upon prevailing weather conditions.

6.0 MEMBRANE APPLICATION:

6.1 Base sheet: DEBOPLAST 2.5 T/F C175 or SOPRASUN PLUS 3 (Mechanically fixed)

Mechanically fixed, APP bitumen membrane base sheet option

Decide the most suitable direction to follow. Unroll the roll and discard packaging. Align and cut to length as required. Laps at each sheet edge shall be 80mm.

Install specified fixings through the edges of the sheets approx. 20mm in from the edge into the substrate following the **EQUUS SOPREMA** project specific fixing layout plan. Ensure the fixings are securely fastened but not overly tightened to deform and/or cut the base sheet. Repeat in sequence with all rolls. Torch this lap closed. Offset end laps in adjacent runs if possible.

Note: The **DEBOPLAST 2.5 T/F C175** or **SOPRASUN PLUS 3** base sheet may be fully torched to the **PERMABASE DEK** roofboard where included in the warm roof system. (see Section 5)

6.2 Base sheet: DEBOFLEX 2.5 T/F C175 (Mechanically fixed)

Mechanically fixed, SBS bitumen membrane base sheet option

Decide the most suitable direction to follow. Unroll the roll and discard packaging. Align and cut to length as required. Laps at each sheet edge shall be 80mm.

Install specified fixings through the edges of the sheets approx. 20mm in from the edge into

the substrate following the **EQUUS SOPREMA** project specific fixing layout plan. Ensure the fixings are securely fastened but not overly tightened to deform and/or cut the base sheet. Repeat in sequence with all rolls. Torch this lap closed. Offset end laps in adjacent runs if possible.

Note: The **DEBOFLEX 2.5 T/F C175** base sheet may be fully torched to the **PERMABASE DEK** roofboard where included in the warm roof system. (see Section 5)

6.3 Base sheet: SOPRASTICK VENTI TACK PLUS (*previously known as DEBOTACK 2.5 T/F C175 AERO*) **(Self-adhesive)**

Decide the most suitable direction to follow. Unroll and align the first roll. Discard packaging. Cut to length as required. Remove the siliconized film and press the membrane into place onto the surface of the insulation. The self-adhesive properties are automatically activated during installation. Light heating is recommended at the edges to ensure all laps are fully closed. Full adhesion is advanced when the **DUO HT 4 SLATES/F C180 FC** cap sheet is finally torched over it. Repeat in sequence with all rolls, maintaining minimum laps of 100mm. Offset end laps in adjacent runs.

6.4 Cap sheet: DUO HT 4 SLATES/F C180 FC (or variant)

Decide the most suitable direction to follow. Unroll the roll and discard packaging. Align and cut to length as required. Re-roll both ends to the middle, then torch evenly to the base sheet as the membrane is unrolled. Ensure even heat application. Repeat in sequence with all rolls, maintaining laps of minimum 80mm. The lap automatically closes during the torching process. All laps shall be offset to prevent coincidence with the base sheet laps. Following application of the cap sheet, all joints are back-sealed separately to ensure they are neatly and correctly closed.

If required, during the back-sealing operation, **DUO MINERAL CHIP** may be carefully scattered over the joint to provide a uniform appearance. This may also be carried out on areas of detailing to provide protection and uniformity of finish.

6.5 Detailing:

Detailing shall be carried out using **DUO HT 4 SLATES/F C180 FC** cap sheet and/or in combination with the **MATACRYL THIX** or **EASY FLASHING** liquid membrane finished with **CHEVALINE DEXX TOPCOAT** or **DUO MINERAL CHIP**. This includes all outlets, pipe penetrations, gutter stop ends, parapet upstands, machinery plinths and anything above or below the roof surface. This is carried out before, during or, in some cases, after laying the membrane, depending on the type of detail. All detailing shall be completed in accordance with the manufacturer's technical literature and the Warm Roof Application Manual current at the time of design, use, installation and/or maintenance.

6.6 Sealant:

ALSAN MASTIC 2200 shall be used where required.

6.7 Membrane Termination:

The membrane will be terminated with **C-PROFILE** and **ALSAN MASTIC 2200** on upstands and parapets as per the manufacturer's termination details.

6.8 Completion:

Upon completion of the system it shall be inspected and left for a short period (up to 2-3 weeks) to stabilize. At this time the entire installation shall be rechecked prior to any warranties being issued. Where possible, particularly on the deck areas, a pond-test (24 hours) should be carried out.

Note: Damage caused to the completed installation by other trades working over the membrane after the initial inspection shall be the responsibility of the Main Contractor, who

shall arrange appropriate protection for the finished membrane system as required.

6.9 Trafficability:

The **EQUUS SOPREMA DUOTHERM** warm roof system is suitable for foot traffic after the installation of compatible **EQUUS FIXPLUS** tile supports, duckboards and roofwalk, or **KRAITEC STEP** rubber tiles.

PERMABASE DEK roofboard shall be installed if additional compressive strength for the roof system is required in areas of high traffic, around plantrooms, air conditioning units and other such roof mounted equipment. This will resist crushing from machinery or plant that may be temporarily placed on the roofing system during maintenance.

The **EQUUS SOPREMA DUOTHERM** warm roof system shall be protected using a temporary protection board before objects are placed on the roof to prevent damage to the waterproofing membrane.

6.10 Photovoltaic Panel Supports (if required):

Where photovoltaic panels are to be installed, **SOPRASOLAR FIX EVO TILT** for bitumen roofs are to be installed as per the installation sheet provided by Equus Industries.

7.0 SPECIFICATION NOTES:

7.1 Quality Assurance (QA):

The Equus Certified Applicator is responsible for onsite QA. The Equus project checklists detailing the required processes shall be completed and signed as each stage of installation is completed. Photographs of each stage shall be taken and submitted as part of the overall QA documentation. A Warranty will not be issued unless a copy has been filed with Equus Industries Ltd. Third party QA documentation is acceptable provided it is in accordance with the Equus issued project QA.

8.0 MAINTENANCE AND WARRANTY:

8.1 Maintenance:

As normal maintenance, Equus Industries Limited recommends that the finished roof areas are inspected every six months for cleaning, and annually, by an Equus Certified Applicator, to ensure weathertightness and durability.

Ensure all outlets are free of blockages and clear of unwanted debris and that all associated flashings and membrane cap flashings are sound. Check the general condition of the membrane and ensure it is free from surface moss, mould, or lichen.

Check all associated building elements that can impact on the durability of the membrane.

Higher risk areas such as sheet joints, substrate movement, edging, gutters, penetrations, corners, upstands, outlets, and overflows require a thorough inspection for weathertightness on an annual basis.

8.2 Warranty:

The **EQUUS SOPREMA DUOTHERM** warm roof system described in this specification may be warranted to be waterproof for a period of up to twenty-five (25) years providing that:

(a) All work is carried out by an Equus Certified Applicator.

(b) The system is installed in accordance with the manufacturers' technical literature and

the **DUOTHERM** Application Manual at the time of design, use, installation and maintenance.

- (c) The warranty is issued in conjunction with the appropriate maintenance statement.

The warranty period shall be determined for any contract in consultation with the Manufacturer or their representative prior to application.

The warranty is provided to the client by the Equus Certified Applicator carrying out the work and is backed by the Manufacturer as to the fitness for the purpose of the materials supplied for the contract.

--oo0oo--