



CELEBRATING  
**40** YEARS  
 1982-2022



# EQUUS SOPREMA EASY FLASHING

Waterproofing membrane applied over existing bitumen membranes or old roofing surfaces

Specification No: P31651

Date Prepared: April 2023

Project & Address:

---



---

Certified Applicator:

---

Building Contractor:

---

Building Owner/Property Manager:

---

## 1. Statement of Intent

- (a) This checklist is to be completed by both the Equus Applicator and the Building Contractor, as a step by step record of compliance with both the Equus Specification provided for the contract, and the requirements of the Manufacturers for Warranty.
- (b) A copy of this checklist must be forwarded to the nearest Regional Office of Equus Industries Ltd. A Warranty will not be issued by Equus Industries Ltd. without a copy of this Checklist being filed.
- (a) A copy of this checklist should form part of the Contract Documentation filed with the Property Manager on job completion.

## 2. Areas Treated

The areas to which the membrane applied are detailed below, with reference to plans (where appropriate).

---



---



---

## 3. Sign Off

We confirm that all applicable processes listed in Section 4 have been correctly completed and that sign-off on each stage has been made by a person with the authority to do so.

For: \_\_\_\_\_ (Signature)  
 (Building Contractor)

Date: \_\_\_\_ / \_\_\_\_ / \_\_\_\_ (Name)

For: \_\_\_\_\_ (Signature)  
 (Equus Applicator)

Date: \_\_\_\_ / \_\_\_\_ / \_\_\_\_ (Name)



#### 4. Checklist And Method Statement

\* Denotes those processes which must be signed off by the Building Contractor as well.

No.	Process	Completed On	Building Contractor	Equus Contractor	Notes
1.	All surfaces shall be treated with Equus <b>Mosskill</b> solution to kill all moss/mould spores and growths.				
2.	all surfaces to be coated shall be thoroughly waterblast cleaned to remove all dirt, moss/ mould residues, surface pollutants and loose or friable paint or cementitious material.				
3.	Strips of 225 or 300 gsm fibreglass mat shall be embedded into wet <b>EASY FLASHING</b> for additional reinforcement around details such as upstands, plinths, penetrations etc.				
4.	Apply first coat of <b>EASY FLASHING</b> at a spreading rate of 1kg/m <sup>2</sup> . Allow to cure for at least 24 hours.				
5.	Apply second coat of <b>EASY FLASHING</b> at a spreading rate of 1kg/m <sup>2</sup> . Allow to fully cure for a minimum of 5 days before topcoat application.				
6.	Apply first coat of <b>Chevaline Dexe Topcoat</b> at a spreading rate of 8-10m <sup>2</sup> /litre. Allow to cure overnight.				
7.	Apply second coat of <b>Chevaline Dexe Topcoat</b> at a spreading rate of 8-10m <sup>2</sup> /litre. Allow to cure for 48 hours before placing in full service.				