



Aquafin 2-K/M Plus

Underground tanking liquid applied waterproofing

Specification No: P5700

Date Prepared: April 2020

Project & Address:

Certified Applicator:

Building Contractor:

Building Owner/Property Manager:

1. Statement of Intent

- (a) This checklist is to be completed by both the Equus Applicator and the Building Contractor, as a step by step record of compliance with both the Equus Specification provided for the contract, and the requirements of the Manufacturer for Warranty.
- (b) A copy of this checklist must be forwarded to the nearest Regional Office of Equus Industries Ltd. A Warranty will not be issued by Equus Industries Ltd. without a copy of this Checklist being filed.
- (a) A copy of this checklist should form part of the Contract Documentation filed with the Property Manager on job completion.

2. Areas Treated

The areas to which Membrane is applied are detailed below, with reference to plans (where appropriate).

3. Sign Off

We confirm that all applicable processes listed in Section 4 have been correctly completed and that sign-off on each stage has been made by a person with the authority to do so.

For: _____ (Signature)
(Building Contractor)

Date: ____ / ____ / ____ (Name)

For: _____ (Signature)
(Equus Applicator)

Date: ____ / ____ / ____ (Name)



4. Checklist And Method Statement

* Denotes those processes which must be signed off by the Building Contractor as well.

No.	Process	Completed On	Building Contractor	Equus Contractor	Notes
1.*	Ensure all concrete surfaces are cleaned sufficiently for application of Equus Chevacrly Admix primer.				
2.	Apply Equus Chevacrly Admix at a diluted rate of 50% water. Allow 4-8 hours to dry depending on prevailing weather conditions.				
3.	Apply a key coat of Equus Schomburg ASOCRET KS/HB to be used in a slurry form (7.5L water to 25kg bag) on all external walls.				
4.	Apply an Equus Schomburg Aquafin 2-K/M Plus bandage using ASO joint tape 2000 to all floor/wall Junctions.				
6.	Apply first coat of Aquafin 2-K/M Plus by brush or trowel at approx. 2kgs per m ² .				
7.	Apply second coat of Aquafin 2-K/M Plus by brush at approx. 2kgs per m ² .				
8.	Check for pinholes and touch up as necessary by means of brush.				
9.	Once Aquafin 2-K/M Plus has cured installation of Equus Danosa Danodren H15 Plus is completed. This is not to be mechanically fixed through the Aquafin 2-K/M Plus waterproofing membrane.				
10.	System to be inspected on completion.				