

NOTE: Fastener spacing to follow De Boer project specific engineered fixing plan.

- ① New corrugated Metal Roof (0.75 gauge minimum)
- ② Equus/De Boer Fastener: RBS50 Tube + BS 6.1 Screw
- ③ Equus Vapour Barrier
- ④ Equus PIR Thermal Insulation Board
- ⑤ Equus/De Boer Basesheet
- ⑥ Equus/De Boer Capsheet DuO HT 4 Slates/F C180 FireCare
- ⑦ Equus/De Boer Capsheet as separate piece over Batten
- ⑧ Equus Roof Cover Board
- ⑨ Roof Equipment
- ⑩ EPDM Washer under Screwhead
- ⑪ Timber Roof Batten

## STEP 2: Fixing of the Equipment

## STEP 1: Fixing of the batten

