




WATERPROOFING

SOPRAVAP'R

ROOFS



SELF-ADHESIVE VAPOUR BARRIER MEMBRANE



SOPRAVAP'R is a self-adhesive vapour barrier membrane composed of SBS modified bitumen and resistant to foot traffic. The width of the membrane was designed so that it fits with the top flutes of most steel deck profiles. Thus, the area covered by a roll is optimized and wastage is reduced. SOPRAVAP'R can also be applied at low temperatures.

- Thermal barrier not required
- Self-sealing properties for mechanically fastened systems
- Fast installation
- Provides a better fit to steel decks, reducing costs associated with wastage

SURFACE PREPARATION

With the exception of steel decks, all substrates must be primed with **Equus Peel & Stick Primer**. The substrate must be clean, sound, and free of loose materials or contaminants, such as water and grease, which may compromise the adhesion of the product.

COMPLEMENTARY PRODUCTS

EQUUS PEEL & STICK PRIMER

Facilitate the adhesion of the SOPRAVAP'R membranes on all substrates, except steel surfaces.

SOPRAVAP'R	
THICKNESS	0.8 mm
DIMENSIONS	40.8 m x 1.14 m (134 ft x 3.7 ft)
SURFACE	Tri-laminated woven polyethylene
UNDERFACE	Silicone release film



www.equus.nz

info@equus.nz

INSTALLATION INSTRUCTIONS

1



Starting at the bottom of the slope, unroll the SOPRAVAP'R membrane to align it, without yet adhering it onto the substrate. Do not immediately remove the silicone release film.

2



Align the roll parallel to the flutes of the steel deck. Make sure membrane overlaps are supported along their entire length.

3



Remove one end of the silicone release film and adhere this part of the membrane to the substrate. Remove the remaining release film at a 45° angle to avoid wrinkling the membrane.

4



Overlap adjacent rolls by 75 mm (3 in). End laps must overlap by 150 mm (6 in). Space end laps by at least 300 mm (12 in).

5



When the vapour barrier is installed directly on a steel deck, place a thin sheet of metal under the end laps of the vapour barrier.

6



The installation is completed.*

* SOPRAVAP'R may be left in place during construction. When left exposed to precipitation, positive slope and adequate drainage is required. The effects of weathering may vary based upon local climate and project conditions. Cover as soon as possible to limit exposure to UV and construction traffic. Not recommended for use as a temporary roof assembly.

If you have any questions about this product or its installation, please contact Equus, your SOPREMA Authorised Distributor.